

# **HorolithVit**





## Powerful acidic disinfectant for milking equipment and milk tanks.

- ▲ Low consumption
- ▲ Less packaging waste

### **APPLICATION**

Pre-clean with water. Clean and disinfect with **HorolithVit** (0.25% - 0.5%, minimum 10 min. at 40°C - 50°C). Rinse with water of drinking quality. To be used in daily rotation with **AseptoVit**.

#### **FEATURES**

To improve milk quality, Ecolab has developed the **VIT** concept (**AseptoVit & HorolithVit**) which provides superior cleaning and disinfecting results. Low application concentrations of **AseptoVit & HorolithVit** reduces packaging waste and transport.

**HorolithVit** is in compliance with the Biocide Product Regulation (No. 528/2012).



#### BENEFITS OF THE VIT CONCEPT

SAFE FOOD: The chlorine free technology facilitates meeting newly established maximum residue limits for chlorate in food.

**ECONOMIC:** Low chlorate content in milk can allow for higher milk

price. The low consumption allows for equivalent hygiene costs.

**WORKER SAFETY:** Optimized pack sizes and low consumption allows for ergonomic handling.

**ENVIRONMENTAL:** The lower concentration reduces the environmental impact through less packaging waste.



#### **SPECIFICATIONS**

HorolithVit		
Physical form	Colourless liquid	
Active substance	Peracetic acid	
pH at 20°C:	0.5 - 1.5	
Density at 20°C (g/cm³):	1.13 - 1.17	
Storage temperature:	-20°C to +30°C	

#### **LOGISTICS**

Packaging	11 kg	22 kg	64 kg	225 kg
Product code	2335960	2332200	2332210	2332220
EAN code	4028162335965	4028162332209	4028162332216	4028162332223

A Material Safety Data Sheet is available on request for professional users. A Product Data Sheet is available on request.

Ecolab Europe GmbH Richtistrasse 7 CH-8304 Wallisellen www.ecolab.com

© 2017 Ecolab. All rights reserved.